

CPI NURAZZO STONE TILE INSTALLATION INSTRUCTIONS

Recommended Products:

Grout	Epoxy, epoxy blend (no sand) - supplied by contractor
Grout Size	1/8 inch
Setting Materials	Laticrete - 254, supplied by contractor
Setting Clips	Required

Post Installation:

Floor Finishing Required Chemistries	H2O surface impregnator
Floor Finishing Pad	Requirement - Gorilla Pad
Floor Service	Clean floor utilizing a red pad, apply H2O impregnator with a mop, allow 15 minutes, mop off. Apply a second application of H2O impregnator with a mop, allow 15 minutes, mop off. Clean floor with standard water and mop. Final step, once the floor is dry, buff entire floor utilizing the supplied gorilla pad.

Standard Maintenance:

Neutral Cleaner pH seven and standard mop or microfiber mop.

Setting Tile Instructions:

Substrate must be free and clear of all debris, suggested that slab is sanded or feather finished to a smooth surface.

Substrate undulation tolerance shall be no greater than 1/8 inch per 10 feet.

Laticrete 254 is to be applied to the substrate using 1/2 square trowel. The tile is to be back buttered. The tile materials are not to be pushed into the setting materials. Setting clips are to be utilized, tiles shall be shimmied-side to side, front to back so to be level to "Surrounding" tile materials. Standard level shall be used to ensure that the product is perfectly level. Setting material coverage shall be no less than 98%.

High Moisture Slabs:

In the case that the concrete conditions are of high Rh. Please consider the following mitigation procedures:

- Mapei - Aqua defense
- Laticrete - Hydra ban

Installation timeframe:

- *Day one - Floor preparation, setting and tile application
- *Day two - Epoxy, epoxy blend grout application
- * Day three - Post installation, floor impregnator application and pad service

